

1.6KVA INVERTER GENERATOR MAINTENANCE MANUAL



This maintenance manual contents regulations which should comply to in daily maintenance and trouble removal on generator.


Please make sure serviceman could read this manual anytime.

This maintenance manual describes the correct maintaining methods. Any personal injury or death or equipment damage, which because ignorance on these regulations, our company would remove the responsibility.

NOTICE :

All rights reserved by our company. Any reprinting without the written permission of our company is expressly prohibited.

SAFETY NOTICE


Your human safety and property are very important as well as others .Please ready following safety notice in this manual and on generator decals, each safety notice has a symbol .




Failure to follow this instruction could result in extreme severe injury.




Failure to follow this instruction might result in severe injury.



Failure to follow this instruction might result in injury.



Failure to follow this instruction, your generator or other property would be damaged.



If no torque written, please refer to appendix -- Torque Table.

CONTENTS


| | |
|---|-------------------------------------|
| GENERAL INFORMATION 第一部分 引言 | 1 |
| Main components 1-1 发电机组成部分 | Error! Bookmark not defined. |
| General parameter | 2 |
| Repair standard | 3 |
| MAINTENANCE 第二部分 保养 | 4 |
| Maintenance table 2-1 保养一览表 | 4 |
| Engine Oil 2-2 机油 | 5 |
| Air cleaner 2-3 空滤器 | 6 |
| Clean fuel strainer 2-4 燃油滤清器的清理 | 7 |
| Spark arrestor 2-5 火花消除器 | 7 |
| Spark arrestor 2-6 火花塞 | 8 |
| Valve clearance adjustment 2-7 气门间隙调整 | 9 |
| FAILURE PREDICTION AND REPAIR 第三部分 故障判定和修理 | Error! Bookmark not defined. |
| Failure prediction 3-1 故障判定 | Error! Bookmark not defined. |
| Start difficultly 3-1-1 起动困难 | Error! Bookmark not defined. |
| Power insufficient 3-1-2 动力不足 | Error! Bookmark not defined. |
| Speed unstable 3-1-3 速度不稳 | Error! Bookmark not defined. |
| Can't ignite 3-1-4 不能点火 | Error! Bookmark not defined. |
| Oil overheating 3-1-5 汽油机过热 | Error! Bookmark not defined. |

| | |
|--|-------------------------------------|
| Abnormal sound 3-1-6 异响 | Error! Bookmark not defined. |
| No DC output 3-1-7 没有直流输出电压 | Error! Bookmark not defined. |
| 3-1-8 Generator Stator Winding too hot 发电机定子绕组过热 | Error! Bookmark not defined. |
| Indicator light judgment 3-1-9 指示灯闪烁判定 | Error! Bookmark not defined. |
| Repair preparation 3-2 维修前的准备 | Error! Bookmark not defined. |
| Safety factors 3-2-1 安全因素 | Error! Bookmark not defined. |
| Special tools 3-2-2 专用工具 | Error! Bookmark not defined. |
| Disassemble diagram 3-3 拆卸图表 | Error! Bookmark not defined. |
| Gasoline engine 3-4 汽油机 | Error! Bookmark not defined. |
| Starter recoil/fly wheel/ignition coil 3-4-1 手起动部件/飞轮/点火线圈 | Error! Bookmark not defined. |
| Carburetor 3-4-2 化油器 | Error! Bookmark not defined. |
| Stepping motor 3-4-3 调速步进电机 | Error! Bookmark not defined. |
| Cylinder head 3-4-4 气缸头/配气机构 | Error! Bookmark not defined. |
| Crankshaft/piston 3-4-5 曲轴/活塞 | Error! Bookmark not defined. |
| Generator 3-5 发电机 | Error! Bookmark not defined. |
| Fuel tank 3-5-1 油箱 | Error! Bookmark not defined. |
| Muffler 3-5-2 消声器 | Error! Bookmark not defined. |
| Frame seat assy 3-5-3 机架底座组合 | Error! Bookmark not defined. |
| Motor assy 3-5-4 电机部件 | Error! Bookmark not defined. |

| | |
|---|-------------------------------------|
| Inverter 3-5-5 逆变器部件 | Error! Bookmark not defined. |
| Control panel 3-5-6 控制面板部件 | Error! Bookmark not defined. |
| Appearance diagram 3-5-7 外观总成 | Error! Bookmark not defined. |
| Wire connecting diagram 第四部分 线路接线图 | Error! Bookmark not defined. |
| Wire connecting schematic diagram 4-1 接线原理图 | Error! Bookmark not defined. |
| Appendix 附录 | Error! Bookmark not defined. |

GENERAL INFORMATION 第一部分 引言

1-1 Main Components 发电机组组成部



General parameter

| Generator model | | R2000iS/ R2000iSP |
|-----------------|--------------------------------------|---------------------------|
| Motor | Type | Silent inverter generator |
| | Frequency /Hz | 50Hz/60Hz |
| | Rated voltage /V | 100V/120V/220V/230V/240V |
| | Max power /kVA | 1.8 |
| | Rated power /kVA | 1.6 |
| | Power Factor | 1 |
| | Waveform deviation factor/% | ≤3% |
| | Noise (3/4 load) | 65dB |
| | DC output / V-A | 12V/8A |
| Engine | Engine model | R80-i |
| | Engine type | OHV |
| | Displacement /cc | 79.7 |
| | Fuel type | Gasoline |
| Engine | Fuel tank capacity /L | 4L |
| | Rated load continuum running time /h | 4 |
| | Engine oil capacity /mL | 380ml |
| | Spark plug model | TORCH-A5RTC |
| | Starting system | Recoil starter |
| Diameter | L*W*H /mm | 498×290×459 |
| Net weight /kg | | 22 |

Repair standard

| Components | Items | Standard | Limitation |
|-------------------|--|---|--|
| Gasoline engine | Max unload speed Cylinder pressure | 5800 0.45Mpa at 600rpm | -- -- |
| Cylinder | Inner diameter | 48.6~48.615 | 48.655 |
| Piston | Piston skirt outer diameter Piston-cylinder clearance Inner diameter of piston pin hole Piston pin outer diameter Clearance between Piston pin and piston pin hole | 48.57~48.59 0.01~0.045 11.002~11.01 10.994~11 0.002~0.016 | 48.52 0.135 11.02 10.984 0.036 |
| Piston ring set | Piston ring sets side-gap : first ring/second ring Piston ring sets close gap: first ring/second ring | 0.015~0.05 -- -- -- 0.15~0.30 | 0.12 -- -- -- 0.6 |
| Connecting rod | Inner diameter of smaller end Inner diameter of bigger end Oil clearance of bigger end Big-end side gap: | 11.006~11.017 22~22.013 0.02~0.043 0.45~0.95 | 11.050 22.040 0.1 1.15 |
| Crankshaft | Crank outer diameter | 21.97~21.98 | 21.94 |
| Valve | Valve clearance Intake / Exhaust Outer diameter of valve stem Inner diameter of intake valve guide Outer diameter of exhaust valve guide Exhaust / Intake Contact width of valve seat Spring free length | 0.03~0.08 0.03~0.08 4~4.012 4~4.012 0.6~0.8 28.5 | -- -- 4.060 4.060 2 27.5 |
| Camshaft | Height of cam Intake Exhaust Journal outer diameter | 20.54 20.54 11.965~11.99 | 20.24 20.24 -- |
| Crankcase cover | Inner diameter of camshaft hole | 12~12.018 | 12.048 |
| Spark plug | Clearance | 0.6-0.8 | -- |
| Cap of spark plug | Resistance | 10kΩ | -- |

MAINTENANCE 第二部分 保养

Maintenance table 2-1 保养一览表

Regular maintenance contributes to safety, economic, no malfunction and environmental protection.

警告 Exhaust contents toxic carbon monoxide, please stop the engine before maintenance. If you have to implement the maintenance when generator running, please make sure the working area is draughty.


Regular maintenance table:

| Regular maintenance table | | Each time | 20h or the first month of begin to use (3). | 50h or every 3 months (3) | 100h or every 6 months (3) | 300h or every year (3) |
|---------------------------|-----------------|---------------------|---|---------------------------|----------------------------|------------------------|
| Engine oil | Check oil level | ○ | | | | |
| | Replace | | ○ | | ○ | |
| Air cleaner | Check | ○ | | | | |
| | Clear | | | ○(1) | | |
| Fuel cup | Clear | | | | ○ | |
| Spark plug | Clear | | | | ○ | Replace |
| Valve clearance | Re-adjust | | | | | ○(2) |
| Cylinder head cover | Clear | Every 300h (2) | | | | |
| Fuel tank and strainer | Clear | Every two years (2) | | | | |
| Fuel hose | Replace | Every two years (2) | | | | |


- (1) Please increase the maintenance frequency if generator used in dusty area.
- (2) These items should be maintained by franchised dealer.
- (3) These items should be maintained in proper time interval as requested to insure generator's life.

Oil 2-2 机油


- 1) Put generator on horizontal plane.
- 2) Loosen the bolts as marked, remove the cover. (Pull the cover back slightly and then pull it up)



- 3) Loosen the oil dipstick and empty the oil in crankcase.



- 4) Put generator on horizontal plane, adding new oil until to the upper limit. Tighten the oil dipstick.



- 5) Assemble the cover, tighten bolts.

Note :Every time before use generator, place it on horizontal plane, stop the engine and check oil level.

- 1.Take the oil dipstick and clean the oil.
- 2.Put dipstick in crankcase but tighten it and check the oil level.
- 3.If the oil level is low, please add recommended oil until the upper level.



Recommended engine oil:

SAE 15W -40

Recommended engine oil standard:

API Standard: SE or higher

Oil capacity: 0.38L



小心 If skin contacts to engine oil too frequently, this might result in skin cancer. Please clean the oil on your skin clearly with soap and water immediately.

For environmental protection, please dispose the oil properly. We recommended that put oil in a sealed container and send it to relevant recycle bin. Do not throw oil into refuse dump or other place.


Air cleaner 2-3 空滤器

Dirty air cleaner will affect the air into carburetor. For reducing carburetor faulty, please maintain the air cleaner regularly (As maintenance table shows) and increase the maintenance frequency if generator used in dusty area.



警告




Use gasoline or inflammable solvent to clean air cleaner element could result in fire or explosion. Please clean the element with soap water of unflammable solvent.



注意

Start the generator without air cleaner assembly is prohibited, which will increase engine abrasion.



- 1) Loosen bolts as marked, remove cover, take the screw ③ remove air cleaner cover④.
- 2) Check air cleaner element make sure it is complete and clean.
- 3) If the element is dirty, please clean foam element with detergent, squeeze the water and then drop a drop of oil, squeeze the element.
- 4) Assemble the element and air cleaner cover.



Clean fuel strainer 2-4 燃油滤清器的清理

Fuel strainer is designed for preventing dust into carburetor. If generator isn't used for a long time, please clean fuel strainer after empty fuel tank.

- 1) Remove the cover (refer to air cleaner maintenance step 1), empty fuel tank.
- 2) Squeeze clip④, pull it down, and pull the fuel hose⑤ out, which connected to fuel tank.
- 3) Remove fuel strainer⑥.
- 4) Clean fuel strainer with gasoline.
- 5) Dry it and assemble it back.
- 6) Assemble fuel hose and clip back, open fuel switch, check if any fuel leakage on fuel strainer.
- 7) Assemble cover back.





Spark arrestor 2-5 火花消除器

警告 Gasoline is flammable and explosive. Smoking, open fire and spark are prohibited in working area.

警告 After generator is reassembly, please check if any fuel leakage before starting the generator and make sure work area is dry.

警告 Hyperthermal muffler could result in serious scale. Please maintain muffler after it cool-down.

In regard to clean spark arrestor, please refer to maintenance table. Remove spark arrestor after generator cool-down. If spark arrestor is damaged, please replace it. Clean the carbon deposition with wire brush. Assemble spark




arrestor back, tighten it with screw.

Spark arrestor 2-6 火花塞

Use incorrect model or caloricity of spark arrestor could decrease engine performance and damage it.

If keep engine running, spark plug and muffler would very hot. Please be careful and don't touch them.


- 1) Remove the cover (refer to air cleaner maintenance step 1), spark plug sleeve and cap.
- 2) Put spark plug kit(provide with generator) into spark plug, loosen it and take it down.



- 3) Check spark plug TORCH-A5RTC

If electrode is damaged, insulator is broken, please replace it. If spark plug could be used, then clean the carbon deposition on it with wire brush.

- 4) Adjusting the gap of spark plug, you can bend the electrode slightly to keep the gap between 0.60-0.80 (mm)。



- 5) Check the spark plug retainer. When assemble spark plug, turn it in screw with hand to avoid improper assembly.
- 6) After put spark plug on retainer, press it tightly with spark plug wrench.

The torque of spark plug: 15 N*m

⚠ 小心 Spark plug should be assembled properly and tightly, if not, it may damage the engine.



⚠ 小心 Please use recommended or the same standard spark plug. It is prohibited to use improper spark plug with improper caloricity.

Valve clearance adjustment 2-7 气门间隙调整


There always be clearance between valve end and its transmitted parts, in case of contraction which would affect engine work. If the clearance is in excess, it would result in higher back-pressure and higher noise (abnormal noise from valve) and decrease engine performance. If the clearance is insufficient, it would make the valve can't be sealed totally, which might result in abnormal performance or burning the working surface of relevant parts of valve.

Generally, after 100h or 1 year using, you have to check the valve clearance and adjust it.

- Disassemble these parts in turn: spark plug cap, spark plug, cylinder head cover and gasket.



- Pull the starter coil to make the piston on the top dead center.
- Measure the clearance of valve.




- If the clearance is beyond the standard, please adjust it.

注意

Please measure the clearance after engine cool-down.

- Adjust valve clearance.



Adjustment steps: loosen the tighten bolt, turn the adjustment nut to a proper position, and tighten the adjustment nut.

| | | |
|-----------------|---------|-------------|
| Valve clearance | Intake | 0.03~0.08mm |
| | Exhaust | 0.03~0.08mm |

| | |
|-----------------|-----------------|
| Adjust the bolt | Valve clearance |
| Tighten | Decrease |
| Loosen | Increase |

注意

Excess valve clearance: Both valves open behind, which will decrease the time of air intake and exhaust, lower the opening height of valves, make engine has insufficient air intake and can't exhaust clearly, and result in power decrease. Besides, it will increase the hit between relevant parts of valve and increase parts abrasion.

Insufficient valve clearance: In engine working, heat will expand parts which push valves away, and result in incomplete sealing of valve, power decrease and valve surface burning, even makes valves hit piston.

Part 3 Trouble determine and maintenance

3-1 Trouble determine

3-1-1 Start-up difficult

| Phenomenon | | | Causes | | Methods of elimination |
|-----------------------------|-----------------------|-----------------------------------|---------------------------------------|---|--|
| Cylinder compression normal | Spark plug normal | Fuel system abnormal | Poor flow of oil or oil does not flow | No fuel oil in the oil tank | Add fuel oil |
| | | | | The vent hole on the oil tank is blocked | Evacuate the blocking |
| | | | | The main metering jet is improperly adjusted or blocked | Re-adjust or clean, blow open |
| | | | | The needle valve hole is blocked | Dismantle the needle valve for repairing, cleaning and blowing |
| | | | | The float is stuck or damaged | Repair the float |
| | | oil blow fluently | Fuel is dirty or deterioration | replace oil | |
| | | | oil mixed with water | replace oil | |
| | | | Too much fuel in the cylinder | Discharge of oil, and dry the spark plug electrodes | |
| | | | The fuel marking No. is wrong | use the correct label | |
| | Fuel supply is normal | High voltage wire spark is normal | The spark plug bad | Electrode dirty, carbon deposition | Clearing away the dirt and carbon deposit |
| | | | | Insulator damage, electrode severe ablation | replace spark plug |
| | | | | The electrode gap is wrong | Adjust the electrode gap |
| | | High voltage wire without spark | The spark plug normal | High voltage wire is damaged | Replace high voltage wire |
| | | | | Ignition coil is damaged | Replace the motor stator |
| | | | | Magnet demagnetization | replace the fly wheel |
| | | | | The trigger is damaged | replace trigger |


| | | | | | |
|-----------------------------|-----------------------|---------------------------|--|--|--|
| | | | | The clearance between the ignition coil and the flywheel is abnormal | adjust the gap |
| phenomenon | | | Causes | | Methods of elimination |
| Cylinder compression is bad | Fuel supply is normal | ignition system is normal | Piston ring wearing limit | | Replace with new piston ring |
| | | | Piston ring break off | | replace |
| | | | Cementation of the piston ring | | Clear away the carbon deposit |
| | | | Spark plug gasket not installed or not tightened | | Installed gasket and tighten it |
| | | | The junction surface of the cylinder body and cylinder cover | Check the unevenness of the cylinder cushion, cylinder body, and cylinder cover junction surface | |
| | | | | Tighten the bolts on the cylinder cover as per the torque required and in a certain sequence | |
| | | | Air leakage of the valve | | Check the valve clearance and the valve airtightness, and repair it when necessary |

- If the generator still cannot be started, please send it to our authorized distributor for maintenance and repair.

Spark plug inspection

warning !

- **Ensure that there is no overflowing fuel oil outside the generator, and the sparkplug is not soaked by the fuel oil.**
- **To prevent fire, do not let the spark get close to the spark plug hole.**
- **When you test the spark plug, it is forbidden to use wet hands to hold the high voltage power lines of the spark plug.**
- Turn the fuel switch to "OFF" position and put away the carburetor petrol.
- Remove the spark plug cap and spark plugs.
- Pull the starter handle and let out of the unburned gas.
- Install the spark plug cap.
- Turn the switch to "ON" position




- Let spark plugs of the negative electrode (the threaded portion) through the cylinder head connected to ground, pull the starter handle spark and observed state.

3-1-2 Underpower

| Phenomenon | Causes | | Methods of elimination |
|---|------------------------|--|--------------------------------------|
| The rotating speed increases slowly or even the rotating speed drops down or there is flameout when the accelerator is stepped on | Fuel oil supply system | There is air in the oil line or the oil line is blocked | Drain the air, clearing the oil line |
| | | Improper adjustment of the main metering jet | Re-adjust the main metering jet |
| | | The needle valve opening and the main metering jet in the carburetor are blocked | Cleaning, blowing open |
| | | The switch of oil tank is blocked | Clean and replace the bad parts |
| | | There is carbon deposit in the combustion chamber | Clear away the carbon deposit |
| | | The air filter is blocked | Clean the filter element r |
| | Improper compression | The piston, cylinder and the piston ring are worn. | Replace the wearing parts |
| | | There is air leakage in the junction surface of the cylinder body and the cylinder cover | Replace the cylinder cushion |
| | | The valve clearance is too big (too small) | Re-adjust it |
| | | The valve is not sealed tightly | Repair it |

Inspection of the cylinder pressure.

- Drain the oil in the oil tank.
- Loosen the oil draining bolt of the carburetor and drain the gasoline.
- Dismantle the spark plug cap and the spark plug and install the cylinder pressure gauge on the spark plug hole.
- Pull the starter for several times and measure the cylinder pressure.



3-1-3 Unstable speed

| Phenomenon | Causes | Methods of elimination |
|--------------------------------------|--|--------------------------------------|
| Tapping sound of the generator | The piston, cylinder and piston ring wear too seriously | Replace the wearing parts |
| | The piston pin and the pin hole wear too seriously | Replace the piston or the piston pin |
| | The small end of the connecting rod wears too seriously | Replace the connecting rod |
| Detonation | Overheat of the generator | Check the cause and eliminate it |
| | Carbon deposit in the combustion chamber | Clear away the carbon deposit |
| | The gasoline is unqualified | Replace with qualified gasoline |
| Failure of ignition of the generator | There is water in the float chamber | Clean the float chamber |
| | The electrode clearance of the spark plug is not correct | Adjust the electrode clearance |
| | Fault of the ignition coil | Check and replace the damaged parts |

3-1-4 Failure of ignition

| Phenomenon | Causes | | Methods of elimination |
|---------------------|--------------------|--|--|
| Failure of ignition | Fuel supply series | The fuel oil is used up | Adding fuel oil |
| | | The carburetor is blocked | Check the oil line and clearing out it. |
| | | here is oil leakage in the float chamber. | Repair the float needle valve |
| | | The needle valve is stuck. | Dismantle the float chamber and eliminate the fault. |
| | Ignition series | The sparking plug breakthrough, and there is short circuit of the carbon deposit | Replace the spark plug |

| | | | |
|--|--------|---|--|
| | | The side electrode of the spark plug falls off | Replace the spark plug, and eliminate the stuff that falls off |
| | | The high-voltage cable falls off | replace it |
| | | The ignition coil will breakthrough and cause short circuit | Replace the motor stator |
| | | The stopping line falls on the machine | Find out the short circuit point and re-insulate it. |
| | Others | Serious cylinder scuff, the valve falls off | Repair and replace the damaged parts |

3-1-5 Overheating of the generator

| Phenomenon | Causes | Methods of elimination |
|---------------------------|---|--------------------------------|
| Overheat of the generator | Insufficient engine oil | Add sufficient engine oil |
| | Blocking of the exhaust port | Clearing the exhaust port |
| | Air leakage of fan cover | Repairing the damaged place |
| | Blocking due to the sundries in the cooling fans | Clearing the cooling fans |
| | The deformation of the connecting rod will cause wearing of the piston and the cylinder hole. | Replacing the connecting rod |
| | The cylinder, piston and piston ring are worn | Replacing the wearing parts. |
| | Improper adjustment of the speed controller of the generator, which will cause that the rotation speed is too high. | Re-adjust the speed controller |

3-1-6 Abnormal sound

| Phenomenon | Causes | Methods of elimination |
|---------------|--|------------------------------|
| Tapping sound | The piston, cylinder and piston ring are worn. | Replacing the wearing parts. |
| | The connecting rod, the piston pin and the pin hole are damaged. | Replacing the wearing parts. |
| | The crankshaft main journal wear | Replace the bearing |
| | The piston ring will break off. | Replacing the piston ring |
| | the valve clearance is too big | Adjust the valve clearance |

| | | |
|-------------------------------------|--|----------------------------------|
| Metallic tapping sound at explosion | Too much combustion-chamber deposit | Clearing away the deposit |
| | The fuel marking No. is wrong | Replacing the fuel oil |
| | Overheat of the generator | Check the cause and eliminate it |
| Others | Improper adjustment of the valve clearance | Re-adjust the valve clearance |
| | The connection between the flywheel and the crankshaft is loosened | Reinstalling it |

3-1-7 No DC output voltage

| Phenomenon | Causes | Methods of elimination |
|----------------------|--|---|
| No DC output voltage | Tripping breakers | Find out the cause of the overload and reset circuit breakers |
| | Diode fusing | Please send to company repair station |
| | The circuit connection errors or fall off | To pick up the Lines |
| | Rectifier is damaged and DC winding open circuit | replace the rectifier components, stators |


3-1-8 Generator stator winding overheating

| | |
|---|--|
| Over load | Operators must be stipulated in the generator to adjust load, to avoid overload |
| Generator air duct was blocked, core box of dust covered the surface of the coil is not easy to transfer heat | Regularly check and remove the generator internal obstruction and coverings, and often keep the air duct cleaning, maintain normal cooling conditions |
| Stator winding short circuit or grounding | Check whether the stator winding is short circuit, with a megger. check whether stator winding grounding, repair or replacement of winding for short circuit and grounding |

3-1-9 Indicator flashes

1. Green light on: it means work, generator output;
2. Green light on, red light flashing: overload, generator output
3. Green light off, the red-light flash once, after the interval 3S flash repeat: represents the front end of generatrix voltage is too low, no generator output;
4. Green light off, the red-light flash twice, after the interval 3S repeat: represents engine speed is too low, no generator output;
5. Green light off, the red-light flash three times, after the interval 3S repeat: represents inverter temperature is too high, no generator output;
6. Green light off, the red-light flash five times, after the interval 3S repeat: represents the front end of generatrix voltage is too high, no generator output;
7. Green light off, the red-light flash six times, after the interval 3S repeat: represents output load is too high, no generator output;

Attention: Red light stand for fault indicator light, Green light stand for working indicator light



3-2 Preparation before maintenance

3-2-1 Safety factors

Warning ! If the following precautions are not observed, the warranty of generator will be invalid and generator may be damaged or people may be injured. Therefore, users should be especially careful of the following precautions before using generator:


- 1) Connecting the load strictly following manual on its rating plate; be sure not to run it overload or over-speed or under slow speed of revolution for a long time.
- 2) Using the fuel oil and engine oil of specified ratings, conduct sufficient sediment and filtering before using them. Refueling device should be kept clean and the engine oil should be changed regularly
- 3) Check if the fastening bolts on generator are tight enough regularly and tighten them in time
- 4) Clean air filter elements regularly and replace them when necessary.
- 5) The generator adopts forced air cooling so be sure to clean the sundries and dirt on its parts like cooling fin and wind scooper in time to ensure the normal cooling performance of generator
- 6) Operators should be familiar with the working principles and structure of the generator and know how to operate emergency stop buttons and all the control parts. Be sure to conduct regular maintenance and timely eliminate the faults found; it's prohibited continuing to run the generator after faults happen to it.
- 7) Please be sure to keep the generator at least one meter from buildings and other equipment before operating it and keep good ventilation; Don't put any inflammable (like gasoline and matches) beside the generator or close to the running generator to prevent the fire risk.
- 8) Refuel the generator at the place with good ventilation and with it standstill and no smoking, open fire or spark at the place or fuel oil warehouse.
- 9) Don't overfill the oil tank and the fuel oil shouldn't overflow; if it overflows, the overflowing oil must be cleaned thoroughly and volatilized before starting the generator
- 10) Don't run the generator in a confined space or a place with terrible ventilation.
- 11) When the generator is running or just stopped for a short time, don't touch the muffler to avoid being burned. In order to prevent burn or fire, don't move or store the generator before it cools down.
- 12) Safety Warning Label

- Please read the warning label carefully before using the generator; our company shall not be liable for the personal injuries or equipment damages caused by ignoring the warning label

3-2-2 Special Tools

| Tool Name | Purpose and Remarks |
|--------------------------------|--------------------------------|
| 1. Motor stop lock tooling | when motor tighten add torsion |
| 2. Motor Puller | The removal of the motor |
| 3. The valve adjusting tooling | adjust the valve clearance |

3-3 Disassembly Diagram




3-4 Engine

3-4-1 Recoil Starter/flywheel/ Ignition Coil

Disassembly: check whether the flange clearance is too large or other problems. Please update with new one if it happens.


Disassembly:
Should use a special
tool (3-2-2) to remove.

Recoil starter parts



• Tool


Ignition Coil



1) Recoil starter


Note

- Be careful when you disassembly, do not make the starter coil spring pop up, please take on the gloves when operating
- Be sure the rope without break or wear before installing.




Installation Instructions


a. Put the reset spring in the seat cover, the hook on the outside of the reset spring should hang around the cover gaps and to align the rope groove, then assemble the seat cover to pull on the rope tray. With the starter cover card claws coating oil, then turning left when installing, just make the reset spring inside the hook in starting cover card claws.




b. Knotting on the end of the rope, and then the other end of the rope pull hole some wear out. And then pull on the rope plate coil five laps in counterclockwise direction. Let the start rope through the starter cap hole, in the department to make a pull rope "8"Knot.



c. Install the driven CAM,Torsional, driven plate and middle bolt.




d. Pull the starter rope several times, check if the driven CAM return to status.



2) Check the ignition coil

Spark plug cap

Put the tester (follow the picture) with spark plug cap,



to test the spark plug cap's resistance value

Spark plug cap resistance value: 5Ω

Igniter



Put the tester terminal with the High-voltage wire coil and iron core, to test the secondary side of the coil resistance.

Secondary side of the coil resistance value: $3k\Omega$

Charge Coil


Put the tester (follow the picture) with charge coil, to test the charge coil resistance value.

Charge coil resistance value: 350Ω



3-4-2 Carburetor


Disassemble the Carburetor



Gasoline is by the fuel tank through the fuel filter into the carburetor, fuel filter can filter out the impurities and the gasoline oxide of the tank. If the quality is flawed, there will be some impurities through fuel filter into the carburetor. At same time, gas contained can form gel ingredients after long time deposit will condense out of the colloid, attached to the carburetor parts (such as main orifice), oil and float on the surface. The air is through air filter into the carburetor, it based on the air intake resistance cannot be too big and other factors considering, filtration unit cannot too dense, so some tiny impurities in the air is still can into the carburetor

To clean the carburetor should be clean with specific area. Firstly, to wipe carburetor surface, the cleaning of internal parts can use special carburetor cleaner or industry. Except the impurities, should pay attention to clean the gasoline gum on the surface of the parts. The parts need with compressed air blowing off, cloth or paper will not be used to wipe, in case of pollution again. Blocked poke holes should not use steel wire and other hard objects, it will protect carburetor performance by changing the aperture changes, and it can used or compressed air to clean out of gasoline.

1) The Carburetor Structure



- **No fire.**


3) Carburetor Installation

a) Check the float valve and float valve seat before installation.

b) Use compressed air to clean before installation.

c) Use compressed air to clean before installation.

d) Use compressed air to clean and Lubricate o-ring before installation.




3-4-3 Speed control stepping motor

Check the motor socket within 2 resistance on the diagonal,
resistance value: $50\Omega \pm 7\%\Omega$


If it beyond the value,pls change a new motor


When the electric motor rotating parts center axis, it should not be a hairpin loose phenomenon. If it is, please change a new motor



3-4-4 Cyliner Head

1) Remove/Installation





Valve spring seat :

Remove the front of valve rod from the middle of the spring seat hole.

Please noted that if the cylinder head installed on the cylinder, spring seat ring may be dropped in the crankcase.

2) Inspection/Maintenance/Repairing:

① Valve stem diameter


Using micrometer to check if the valve stem diameter is lower than the standard limit, visible to the naked eye, more maintenance gas appearance has ablation or crack. With above situations, you'd better to change with the new one.

| Standard | | Maintenance Limit | |
|--------------------------|---------------------------|---------------------|---------------------|
| 3.97~3.985 mm (intake) | 3.935~3.95 mm (outtake) | 3.900 mm (intake) | 3.88 mm (outtake) |

② Valve spring length

Measure the valve spring length.

If lower than the standard or out of maintenance period, please use new one.




| Standard | Maintenance Limit |
|----------|-------------------|
| 28.5mm | 27.5mm |

③ Valve guide pipe

Check :

a) check whether the valve guide pipe surface smooth or not, and without scratches and strain; valve guide pipe should cooperate well with the cylinder head.




b) Use the valve reamer to remove the carbon deposition before measuring inner diameter.

If lower than the standard or out of maintenance period, please use new one.

| Standard | Maintenance Limit |
|-----------|-------------------|
| 4~4.012mm | 4.060mm |

Replacement:

- To replace the valve guide into the freezer frozen 1 hour or so
- Use the valve guide puller to remove the valve guide pipe from combustion chamber side.



Noted

When remove the valve guide, do not damage the cylinder head.


- Put the new valve guide pipe from the cylinder head valve spring

Exhaust valve side :

Knock the exhaust duct until the retaining ring in contact with the cylinder cover completely.

Intake valve side : Tapping into the valve guide until the prescribed height (measured from the top of the valve guide to the cylinder head surface)

- After installation, please check whether there is any damage on valve guide pipe, if there are any damages, please use new one.



Reamer :


It is better to hinge the reamer with room temperature.

- The valve reamer and valve tube coated with cutting oil. With the reamer screwing clockwise until all reamer screwing in the valve guide. Then according to clockwise pulled out the reamer from the valve guide pipe.

Tool : reamer

b) Thoroughly remove dirt and debris on the cylinder head.

c) Check valve guide hole, the hole should be located in the central and should be unobstructed. If not, the valve guide pipe may have been bent. With this bad situation, you should use a new one.




d) Check the clearance between the catheter and the valve stem.

e) Clearance between the valve stem and valve guide: the valve guide inner diameter minus the valve guide stem.

f) If the clearance between the valve stem and catheter values is out of maintenance limit, you should decide to replace a new catheter to clearance within the limit of maintenance, if so, replace the valve guide and stick ground valve guide. When replace the valve guide, you need rebuild the valve seat.

④ Valve seat :


a) Completely clear the carbon deposition which on the combustion chamber and the valve seat, then smearing a thin layer of red lead powder, or other different wipe easily adhesion of the coating color.



b) Insert valve and pushing valve a few times, but make sure do not rotate the valve on the valve seat. Developed coating valve seat, it shows that the closely with the valve; On the other hand, if it not, it suggests that different heart valve and valve seat.


c) With 45 ° mill to grind cutting, the valve seat to create a smooth concentric valve seat, only clockwise.

Tool : Valve grinding machine



d) Using 32 ° to 45 ° mill to reduce and adjust the valve seat, to let it contact with the valve cone parts.


- Using 32 ° mill grinding valve seat at the top of the half edge (too high).
- Using 45 ° mill grind the valve at the bottom of the edge contact (too low).



| Standard | Maintenance limit |
|-----------|-------------------|
| 0.6~0.8mm | 2mm |

e) Using the 45 ° slight grinding mill to remove any burr on the edge of the valve seat.


f) After rebuilt the valve seat, should be check the width of the valve seat. In the valve cone colorants, only insert valve and pushing valve a few times, but not sure that the valve on the valve seat. Valve seat's cone




stained uniform coloring as shown, the valve and valve seat's cone good contacts

g) On the valve seat's cone daub abrasives, use tool rotation to the valve seat to get up to speed.

valve grinding



h) Check valve clearance after installation.




3-4-5 Crankshaft/Piston

① Installation

a) Piston

- Use supplier mark up during installation. Be careful not to put first ring confused with second ring (a ring with chrome plating).
- After installation to confirm piston ring.
- Make each piston ring opening to avoid the direction of the piston pin, and 120 °.


b) Piston pin retainer ring



Put the front at the piston groove, then using long nose pliers clamp at the other end, turning install it in the slot at the same time. But you should avoid the gap of the piston ring.

c) Connecting rod cover

When installation, you should put the edge of connecting rod and connecting rod at same position.



② Detection of piston

Check the contact situation, the piston and cylinder top ring groove defect, ablation and crack etc. If the damage is serious, you should use the new one.

Remove the carbon deposit

The carbon deposit located on the top of the piston and cylinder flowing edge part. You should be cleared away before testing carbon deposit. Firstly use kerosene wet saturated carbon deposit, and then be removed using a blunt knife or metal brush.

a) Piston skirt diameter


Piston skirt diameter is measured with outside micrometer, if it beyond the limit, it shall be replaced.



| Standard | Using limit |
|---------------|-------------|
| 48.57~48.59mm | 48.655mm |

b) The clearance of piston pin hole and piston pin

With inside diameter micrometer to measure the piston pin hole diameter, and outside micrometer to measure the piston pin outer diameter. Then calculated by the measured results. If it beyond the limit, you can change the piston or piston pin with your own need.



| Standard | Using limit |
|----------------|-------------|
| 11.002~11.01mm | 11.02mm |

b) Piston- Cylinder gap


The biggest diameter of the cylinder minus the piston skirt diameter

Note

Be tested the gap before and after repairing.

When you checking, the inverted piston should be in the cylinder, put the appropriate thickness gauge on the pressure surface between the cylinder wall and piston skirt, and then take out feeler gauge, if you feel some certain resistance, but you also can smooth out, that is clearance between the piston and cylinder.

| Standard | Using limit |
|--------------|-------------|
| 0.01~0.045mm | 0.135mm |




c) The gap of piston ring side

Piston ring should be free rotation, neither loose nor sluggish acerbity. Then insert ring and groove in the plane of the upper and lower clearance with a feeler gauge in the measurement

| Standard | Using limit |
|--------------|-------------|
| 0.015~0.05mm | 0.12mm |

e) Piston ring closure gap

Put the piston ring into the cylinder, push the piston ring head to the work position, and then use the gauge to measure the opening gap. The gap should not too big nor too small. Too big, it will make the cylinder sealing performance get poor, when it starts, the piston ring will be expansion and stucked in the cylinder. If the ring opening gap is small, usable fine flat file filing. The file should be put inside the cylinder to check, until clearance is fitting.



| | Standard | Using limit |
|------------------------|-------------|-------------|
| First ring/Second ring | 0.15~0.30mm | 0.6mm |

③ Detect the connecting rod


If the connecting rod bending, distortion, or cracking etc., you should the replacement of new parts.

a) Detection of small diameter

If lower than the standard limit or out of using limit,

Replace with new one.

| Standard | Using limit |
|-----------------|-------------|
| 11.006~11.017mm | 11.050mm |




b) Detection of big diameter

If lower than the standard limit or out of using limit,

Replace with new one.

| Standard | Using limit |
|-------------|-------------|
| 22~22.013mm | 22.04mm |




④ The detection of the camshaft

Camshaft is gasoline engine driving parts, it controls the inlet and exhaust valve opened or closed according to certain rule.

Structure characteristics: satisfy the requirement of control inlet and exhaust shaft with CAM and supporting shaft neck. When the camshaft working, it bear the impact load of cyclical, camshaft face friction with the lifter, it is easy to wear or scratch. Therefore, camshaft should have good lubricity and wear-resisting.

- Check the camshaft if there is any damage on the surface, the camshaft and bearing is loose, wear or tear .If it is ,you should replace all of them.


Check the height of the camshaft, when the height less than the maintenance period, you should replace the camshaft.



| | Standard | Maintenance limit |
|-------------------------|----------|-------------------|
| Camshaft height intake | 20.54mm | 20.24mm |
| Camshaft height outtake | 20.54mm | 20.24mm |

- Check the camshaft neck diameter, if it is less than the standard, you should replace camshaft

| Standard | Maintenance limit |
|----------------|-------------------------|
| 11.965~11.99mm | Using with the standard |




Wear reasons and affect for the engine performance:

Camshaft is wearing and tearing, the main reason is poor lubrication, such as low oil viscosity, impurities, small amount of circulating oil etc., cannot make the camshaft surface full oil film which lead to the camshaft with high speed dry friction state of the surface wear serious. The accuracy installation is the second reason. When the camshaft neck and camshaft bearing fitting clearance between super bad, camshaft rotating accuracy decreased, and the related parts of biased contact surface caused by abnormal wear.

⑤ Timing gear

Check the timing gear meshing clearance, it should keep on the involution marks location on both sides of the gear



Timing gear main wear by tooth wear, tooth surface spalling or coarse gear, gear tooth broken etc. Due to the tooth wear, the bigger the meshing clearance, the greater the noise.


If the timing gear surface touch, lack of Angle, injury or damage, it should replace new one.

Note

It is best to replace the entire new parts, in order to match the meshing.

3-5 Generator


3-5-1 Fuel Tank



Note Installation attention

- Check whether there is any jam on vent oil before installation.
- Weather the fuel filter is blocked or damaged
- Weather the fuel hose is presence of aging and rupture.
- If have any problems, you should replace a new one before installation

3-5-2 Muffler



Note

Disassembly muffler as above picture

Muffler long-term use can cause carbon deposits, that can give the exhaust system a serious impact. In order to make sure exhaust system work better, we generally remove carbon deposits in muffler.

When removing carbon deposits in mufflers, plastic hammer is available to tap and use compressed air to remove

If the muffler reservoir drops, corrosion severely, so that the exhaust noise increases, should be replaced with new parts.


Note

Do not clean with iron wire, otherwise it may result in sound deadening material to fall out, thereby reducing the noise reduction performance. Muffler gasket cannot be reused.

Warning

- **Muffler may very hot, keep the gasoline engine out of reach of passer and children.**
- **When the gasoline is running, do not place any flammable materials near the exhaust port.**

3-5-3 The chassis base composite



3-5-4 Motor parts

1) Disassembly and assembly :


Rotor

Clean dust or oil on the tapered portion of the crankcase and the rotor, and then install.


Nut: M12×1.25

Torque value: (26-30) N·m


Plug



Put the main output winding wire in the bottom of the engine, and then put the engine in the engine damping seat on the baseboard



2) Check



The main winding / winding power / DC winding.

No direct current output check whether the DC over current tripping, whether the DC socket is damaged. If damaged, replace the outlet.

No alternating current output check the AC outlet whether damage. If damaged, replace the outlet

Check whether the voltage between the electric motor stator and power windings. If there is voltage, replace the inverter. If there is no voltage, replace the stator

Note: To be careful when removing and installing the stator, to avoid damage winding wire and wire insulation.

Warning

Once the winding insulation resistance decreased, which means between the winding and the insulation has been damaged, if not promptly take measures to repair which would cause leakage, and endanger the people's and equipment safety. Learn for early winding insulation, be sure always measure the winding insulation resistance.

- **Winding insulation resistance against ground testing**


An any one of terminal of insulated wire winding connect to one terminal of test megger through insulation wire. And the other terminal connected to the core. Then handing megger from slow to fast. Hands along with yaw,when the hands steady which is the value indicated is the winding insulation resistance.

- **Generator windings circuit detection**

Using a multimeter electrical barrier test. Using multimeter red, black pen were exposed to both ends of the winding wire.If hands normal yaw, indicating that winding without disconnection.If the hands do not move, indicating that the tested winding can't get through, disconnection..

3-5-5 Inverter unit.

1) Removing and installing :



2) Checking


Invert Parts

注意


Inverters need to be detected in the generator operating state

Checking the wire on the inverter whether have color change. The upper inverter filled resin whether have blister-like projections. Checking all electrical components on the inverter, connectors and wiring no visible color change or damaged .


Input is Shorted Circuit (Low-voltage): Red Light. Green light off and no output. Using test megger (Low-voltage) detect low voltage socket, if the voltage is zero or below 5V, check the engine speed is normal or motor winding output voltage is too low.



Input is shorted circuit(three-phase): Red light, green light off and no output. Using test megger (High-voltage) detect high voltage socket if the voltage is zero or less than 150V, check the engine speed is normal or motor winding output voltage is too low.




Output short Circuit: green light off, red light on. After disconnecting the output voltage of the inverter output. Using test megger Voltage detect detector profile, if the voltage is zero, replace the inverter.



Sensitive Switch

When spring is in the bounce state sheet, with an ohmmeter measure resistance between two output terminals. If the resistance is zero, replace the micro switch.



When the spring plate in a compressed state, with an ohmmeter measure resistance between two output terminals. If infinite resistance, replace the micro switch.



Rectifier

Rectifier bridge internal circuit as picture shown above. Multimeter to check each terminal of the rectifier bridge on/off

It's When the rectifier bridge instructions show on/off its instructions below normal.



Tip 1: "Continuous" refers to a diode conducting special


Resistance

which is different from the short circuit

when the check fails for any period,


Replacement of a bridge rectifier.

| Multimeter | | Red Pin ⊕ Test | | | |
|------------------|-------|----------------|------|-----|--------|
| | | Blue | Blue | Red | Blackk |
| Black Pin ⊖ Test | Blue | | Off | Off | On |
| | Blue | Off | | On | On |
| | Red | On | On | | On |
| | Black | Off | Off | Off | |




3-5-6 Control Panel Componts


1) Remove and Equipped





Checking Combination Switch




When the combination switch in each position. Checking the ignition circuit, fuel switch, choke switch status

Close switch  is "OFF", the ignition circuit is turned off, namely two micro switch output terminal is turned on, the ignition grounding; oil switch is turned off, the engine would not run.

When the combination switch  is "ON", the ignition circuit is in working condition, that both the output terminals micro switch off; oil switch is turned on; the choke is fully open state, the engine can be run properly.

When the combination switch in the  "CHOKE", the ignition circuit is in working condition, that two output terminals micro switch off; oil switch is turned on; the choke in the closed state.




When the switch is in the respective positions. The continuity between the switch terminals to be checked.

WIRE

Removing the wire harness from the panel, rectifier and the inverter. Check wire insulation for any obvious damage. If it is damaged, replace the harness.


Using an ohmmeter check continuity of each wire, confirm that each wire is turned on. If infinite resistance, replace the harness.



NOTE: Use tongs when removing and tipping harness, to avoid damage to the wire and wire connectors with appropriate force.

Oil Alert Indicator (Red)


When the crankcase oil drops below the safety line, oil protection system will automatically shut down the engine, and the oil warning indicator light; add oil to the engine oil level, engine can start again.



Tip: If the engine stall or not start rotating power switch knob to the "ON" position, then pull the handle to start,
If the oil warning light blinks for a few seconds, the engine oil capacity is insufficient, add oil and restart. Check with ohmmeter indicator to confirm conduction, if infinite resistance, replace the lamp.

Fault indicator (red)

Fault indicator is on, the detected output of the generator is connected to the electrical equipment has been overloaded, resulting in a Inverter overheating, or AC in pressure. In this case, AC protection work to stop this generator, in order to protect the generator and electrical equipment connected. AC indicator (green) goes off and the fault indicator (red) lights up, but the engine will not stop running operation.



When the fault indicator lights up, and the unit when there is no output, please take the following countermeasures:

1. Turn off electrical equipment connected, stop the engine.
2. Turn off all the connected electrical equipment total power to the range of the rated output.
3. Check whether the cold air inlet blockage, there are problem related to the control means. If abnormal excluded immediately.
4. After checking, restart the engine.


Tip: When using a high starting current electrical equipment (such as compressors, submersible pumps, etc.), beginning fault indicator may light a few seconds, but this is not mentioned above failures.

Check with ohmmeter indicator to confirm conduction, if infinite resistance, replace the lamp.

AC indicator (green)


Start the engine and normal output, AC indicator light up.

Check with ohmmeter indicator to confirm conduction, if infinite resistance, replace the lamp.



DC circuit breaker

When connected to a generator of electronic equipment operation, if the current exceeds the rated current, the DC switch automatically go to "OFF" position. The generator operation




ON

OFF


again, set the DC switch Press the "ON" position.

Checking continuity between the terminals of the DC circuit breaker with a multimeter.

The conduction should be on when the button of Circuit breaker is pressed.




3-5-7 Exterior Assembly



ART Wiring diagram

agram



Attachment

Torque Sheet

| Item No. | Items | Thread Size | Grade | Torque (N.m) |
|----------|---|------------------|-------|----------------|
| 1 | Shroud, Muffler | ST4.8×16 | 4.8-A | 4±1 |
| 2 | Starter rope guide plate combination | M5×12 | 4.8-A | 4±1 |
| 3 | Cover, RH LH (底板连接处) | M6×19 (六角台阶螺栓) | 8.8-B | 9±1 |
| 4 | Side cover, muffler | M5×16 | 4.8-A | 4±1 |
| 5 | Fuel switch combination | M6×12 | 8.8-B | 10±2 |
| 6 | Support, Invert | M6 | 8-A | 9±1 |
| 7 | Invert | M6×12 | 8.8-A | 9±1 |
| 8 | Control Panel Assy | ST4.2×16 | 4.8-A | 3±1 |
| 9 | Support, Control Panel | M6×12 | 8.8-A | 9±1 |
| 10 | | M5×16 | 4.8-A | 4±1 |
| 11 | Cover, Decorative Plate, RH,LH | M5×12 | 4.8-A | 3±1 |
| 12 | Support, Fuel Switch | ST4.2×16 | 4.8-A | 4±1 |
| 13 | Rotater | M4×16 | 4.8-A | 3±1 |
| 14 | Cover, LH,RH (Rubber, Fuel injection) | ST4.2×16 | 4.8-A | 3±1 |
| 15 | Cover, LH,RH (Handle bar) | M5×16 | 4.8-A | 3±1 |
| 16 | Impeller | M6×10 | 8.8-A | 9±1 |
| 17 | Magnetic rotor housing combinations | M12×1.25 | 8-A | 28±2 |
| 18 | Rectifier | M4×16 | 4.8-A | 4±1 |
| 19 | Magnetic rotor housing combinations... | M5×35 | 5.8-A | 6±1 |
| 20 | Shroud, Alternator | M6×30 | 8.8-A | 9±1 |
| 21 | Absorber, Frame | M6×12 | 8.8-A | 9±1 |
| 22 | | M6 | 8-A | 9±1 |

| | | | | |
|----|-----------------|-------|-------|-----|
| 23 | Absorber, Frame | M6×14 | 8.8-A | 4±1 |
|----|-----------------|-------|-------|-----|

Standard torque parameters

| Fastening Parts | Thread Size | Torque (N·m) |
|-----------------|-------------------|----------------|
| SCREW,BOLT | 5mm SCREW,BOLT | 4.5-6 |
| | 6mm SCREW,BOLT | 8-12 |
| | 8mm SCREW,BOLT | 18-25 |
| | 10mm SCREW,BOLT | 29-34 |
| | 12mm SCREW,BOLT | 49-59 |
| | 4mm SCREW | 1.5-2.6 |
| | 5mm SCREW | 3.5-5 |
| | 6mm SCREW | 7-11 |
| | 5mm Flange bolts | 3.6-6.9 |
| | 6mm SCREW | 7-11 |
| | 5mm Flange bolts | 3.6-6.9 |
| | 6mm Flange bolts | 10-14 |
| | 8mm Flange bolts | 20-26 |
| | 10mm Flange bolts | 35-45 |
